

- Do not drop or knock the unit since it incorporates many precision-adjusted component parts.
- Do not attempt to replace or modify any

internal component part yourself. Such tampering invalidates any warranty, and such units will not be accepted for repairs by the manufacturer.

## **OPERATION**

**First turn the amplifier power switch off before commencing cable connections to the XF-1.**

1. Connect the tonearm output cable to the XF-1 INPUT terminals (checking that left and right channels are properly connected), and attach the ground lead to the GROUND terminal.
2. Connect the XF-1 output cable to the PHONO terminals of the amplifier, and the ground lead to the ground terminal. (Red cable for right channel, and white cable for left channel).

